

draw need not open. Public vessels of the United States, tugs with tows, and vessels in distress shall be passed at any time.

(b) The drawspan for the SR84 Draw-bridge, mile 4.4 at Fort Lauderdale, must open on signal if at least 24 hours notice is given. Public vessels of the United States and tugs with tows must be passed through the draw as soon as possible.

[USCG-2001-10881, 71 FR 70310, Dec. 4, 2006; 72 FR 7351, Feb. 15, 2007]

#### § 117.317 Okeechobee Waterway.

(a) *Exempt vessels.* This term means public vessels of the United States and tugs with tows.

(b) *Evans Crary (SR A1A) bridge, mile 3.4 at Stuart.* The draw shall open on signal; except that from December 1 through May 1, from 7 a.m. to 6 p.m., Monday through Friday, except federal holidays, the draw need open only on the hour and half-hour. On Saturdays, Sundays, and federal holidays, December 1 through May 1, from 8 a.m. to 6 p.m., the draw need open only on the hour, 20 minutes after the hour, and 40 minutes after the hour. Exempt vessels shall be passed at any time.

(c) *Florida East Coast Railroad bridge, mile 7.4 at Stuart.* The draw shall operate as follows:

(1) The bridge is not constantly tended.

(2) The draw is normally in the fully open position, displaying flashing green lights to indicate that vessels may pass.

(3) When a train approaches the bridge, the navigation lights go to flashing red and a horn sounds four blasts, pauses, and then repeats four blasts. After an eight minute delay, the draw lowers and locks, providing the scanning equipment reveals nothing under the draw. The draw remains down for a period of eight minutes or while the approach track circuit is occupied.

(4) After the train has cleared, the draw opens and the lights return to flashing green.

(d) *Roosevelt (US1) bridge, mile 7.4 at Stuart.* The draw shall open on signal; except Monday through Friday, except Federal holidays, from 7 a.m. to 6 p.m. the draw need open only on the hour

and half hour. However, the draw need not open between 7:30 a.m. and 9 a.m. and 4 p.m. and 5:30 p.m. except at 8:15 a.m. and 4:45 p.m. On Saturdays, Sundays, and federal holidays from 8 a.m. to 6 p.m. the draw need open only on the hour, 20 minutes after the hour, and 40 minutes after the hour. When the adjacent railway bridge is in the closed position at the time of a scheduled opening the draw need not open, but it must then open immediately upon opening of the railroad bridge to pass all accumulated vessels. Exempt vessels shall be passed at any time.

(e) *Seaboard System Railroad bridge, mile 28.2 at Indiantown.* The draw shall open on signal; except that, from 10 p.m. to 6 a.m. the draw shall open on signal if at least three hours notice is given.

(f) *Florida East Coast Railroad bridge, mile 38.0, at Port Mayaca.*

(1) The bridge is not constantly tended.

(2) The draw is normally in the fully open position displaying flashing green lights to indicate that vessels may pass.

(3) When a train approaches the bridge it will stop and a crewmember will observe the waterway for approaching vessels, which will be allowed to pass. Upon manual signal, the bridge lights will go to flashing red, and the horn will sound four blasts, pause, then repeat four blasts, then the draw will lower and lock, providing scanning equipment reveals nothing under the span.

(4) After the train has cleared, the draw will open, and the lights will return to flashing green.

(g) *Belle Glade Dike (SR 71) bridge, mile 60.7 between Torry Island and Lake Shore.* The draw shall open on signal from 7 a.m. to 6 p.m. Monday through Thursday, and from 7 a.m. to 7 p.m. Friday through Sunday. At all other times, the draw need not be opened for the passage of vessels.

(h) *Seaboard System Railroad bridge, mile 78.3 at Moore Haven.* The draw shall open on signal; except that, from 10 p.m. to 6 a.m. the draw need not be opened for the passage of vessels.

(i) *Highway bridges at Moore Haven (mile 78.4) La Belle (mile 103.0), Denaud (mile 108.2), Alva (mile 116.0), and Olga*

### § 117.319

(mile 126.3). The draws shall open on signal; except that, from 10 p.m. to 6 a.m. the draws shall open on signal if at least three hours notice is given.

(j) Sanibel Causeway bridge, mile 151 at Punta Rassa. The draw shall open on signal, except that from 7 a.m. until 6 p.m. Monday through Friday, except Federal holidays, the draw need only open on the hour and half hour. On Saturday, Sunday, and Federal holidays the draw shall open on signal, except that from 7 a.m. until 6 p.m., the draw need only open on the hour, quarter hour, half hour and three-quarter hour. From 10 p.m. until 6 a.m. daily, the draw shall open on signal if at least five minutes advance notice is given to the bridge tender.

(k) *Caloosahatchee River Bridge (SR 29), Mile 103, Labelle, Florida.* The Caloosahatchee River bridge (SR 29), mile 103, shall open on signal, except that from 7 a.m. to 9 a.m. and from 4 p.m. to 6 p.m., Monday through Friday, except Federal holidays, the bridge need not open. Exempt vessels shall be passed at any time.

[CGD7 85-50, 51 FR 12319, Apr. 10, 1986]

EDITORIAL NOTE: For FEDERAL REGISTER citations affecting §117.317, see the List of CFR Sections Affected, which appears in the Finding Aids section of the printed volume and at [www.fdsys.gov](http://www.fdsys.gov).

### § 117.319 Oklawaha River.

(a) The draw of the Sharpes Ferry (SR 40) bridge, mile 55.1 shall open on signal if at least three hours notice is given.

(b) The draw of the Moss Bluff (SR 464) bridge, mile 66.0, need not open for the passage of vessels.

(c) The draw of the Muclan Farms bridge, mile 63.9, need not open for the passage of vessels.

[CGD7-85-15, 50 FR 29672, July 22, 1985, as amended by CGD7-87-49, 52 FR 42649, Nov. 6, 1987; CGD07-02-008, 67 FR 50351, Aug. 2, 2002]

### § 117.323 Outer Clam Bay.

The drawspan of the Outer Clam Bay Boardwalk Drawbridge shall open on signal if at least 30 minutes advance notice is given.

[CGD07-06-237, 72 FR 11777, Mar. 14, 2007]

### 33 CFR Ch. I (7-1-14 Edition)

### § 117.324 Rice Creek.

The CSX Railroad Swingbridge, mile 0.8, in Putnam County, shall open on signal from 8 a.m. to 4 p.m., daily. From 4:01 p.m. to 7:59 a.m., daily, the bridge shall open with a 24-hour advance notice to CSX at 1-800-232-0142.

[CGD07-03-094, 69 FR 1919, Jan. 13, 2004]

### § 117.325 St. Johns River.

(a) The drawspan for the Main Street (1/SR 90) drawbridge, mile 24.7, at Jacksonville, must open on signal except that, from 7 a.m. to 8:30 a.m. and from 4:30 p.m. to 6 p.m., Monday through Saturday except Federal holidays, the drawspan need not be opened for the passage of vessels.

(b) The draw of the Florida East Coast automated railroad bridge, mile 24.9, shall operate as follows:

(1) The bridge shall be constantly tended and have a mechanical override capability for the automated operation. A radiotelephone shall be maintained at the bridge for the safety of navigation.

(2) The draw is normally in the fully open position, displaying flashing green lights to indicate that vessels may pass.

(3) When a train approaches, large signs on both the upstream and downstream sides of the bridge flash "Bridge Coming Down," the lights go to flashing red, and siren signals sound. After an eight minute delay, the draw lowers and locks if there are no vessels under the draw. The draw remains down for a period of eight minutes or while the approach track circuit is occupied.

(4) After the train has cleared, the draw opens and the lights return to flashing green.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD7-90-76, 55 FR 47753, Nov. 15, 1990; CGD07-96-069, 62 FR 15843, Apr. 3, 1997; CGD07-05-009, 70 FR 18991, Apr. 12, 2005; USCG-2001-10881, 71 FR 70310, Dec. 4, 2006; USCG-2012-0306, 77 FR 37314, June 21, 2012]

### § 117.327 St. Marks River.

The draw of the U.S. 98-SR30 bridge, mile 9.0 at Newport, need not be opened for the passage of vessels.

[CGD8-88-13, 54 FR 13064, Mar. 30, 1989]